

#### ProHX/Pro2 Pro31/AR51 Pro3/300/AR56 AF dimension of wrench


WRENCH SIZES

bigger by 1/32'

2"

21/16"

23/8"





Socket



# FatBoy<sup>™</sup> Wr∈nch

Heavy-duty wrench is designed for use with all makes and models of plate heat exchangers. The Fatboy™ is made in the USA of high quality steel and powder coated for years of reliable service. State distance across flats of nuts (AF-see above) when ordering.



# AGC Leather Gloves

Protect your hands from cuts! These gloves are perfect for handling plates or tightening units. Shoulder leather gloves feature a white canvas back and washable white duck cuff.  $2^{1/2}$ " safety cuff.



# Western

9109 SE 64th Ave. Portland, OR 97206 503.774.7342 800.715.8820 FAX 503.774.2550

### Central

1325 Remington Rd. Suite T Schaumburg, IL 60173 847.301.6890 FAX 503.774.2550

See us on the web at www.AGCHeatTransfer.com

#### Eastern

10129 Piper Lane Bristow, VA 20136 703.257.1660 800.825.8820 FAX 703.330.7940

AMERICAN MADE **DLO** Accessories

# ACCESSORIES





Model PD2 and PD3 Silencer<sup>¬</sup>

## AGC Pulsation Dampener Liners

Genuine AGC replacement liners for the Silencer<sup>™</sup> and the APV "condom" style pulsation dampeners. Please specify type and size when ordering.



# Special 1099 Plate Gasket Glue

This glue is the standard contact cement used for gluing plate heat exchanger gaskets to plates. Available in tubes or quarts with application bottles as required.



#### Western

9109 SE 64th Ave. • Portland, OR 97206 503.774.7342 • 800.715.8820 • FAX 503.774.2550

#### Central

1325 Remington Rd. • Ste T • Schaumburg, IL 60173 847.301.6890 • FAX 503.774.2550

#### **Eastern**

10129 Piper Lane • Bristow, VA 20136 703.257.1660 • 800.825.8820 • FAX 703.330.7940







# AGC Speciality Inspection Dies

RED and WHITE Visible Inspection Fluid — Designed to check for pinholes in plate heat exchanger plates. The spray comes in two parts. Part one is the red penetrant and part two is the white developer. Normally used for checking small numbers of plates in the field. Normal usage is two parts white (developer) to one part red (penetrant).

#### FOOD GRADE INHIBITED CIRCULATE DYE

This specially developed liquid concentrate comes in 1/2 gallon quantities. For use by trained personal to circulate in series through the plate and open to visually inspect for pinholes. Normal usage is 1/2 gallon per 100 gallons or two 1/2 gallons per typical HTST Pasteurizer.



See us on the web at www.AGCHeatTransfer.com